# ergotron How to choose your desk attachment

## **HX Desk Monitor Arm**


## Standard 2-Piece Desk Clamp


#### This is the most common option



- · This is the most common option.
- It can slide on from back or side of desk.

  It can also disassemble to attach when no space behind desk is available.
- Requires space under desk.
   Works with wide variety of desk sizes and shapes.
- Also available as accessory.







## C-Clamp (under mount)

#### Less common option



- Used in Pro-office furniture systems.
- Use when the space for clamp under desk is very limited.
   \* Requires 1.2" (31 mm) from edge of desk to slide on from the back or can slide on from the side if possible.
- Also available as accessory.
   Has 0.8" (2cm) setback from edge of desk to allow room for divider panels.






## Low Profile Clamp (top mount)


#### Less common option



- · Recommended for height adjustable desks.
- Use when there is a need to attach clamp from above the desk.
- · Use when the space for clamp under desk is very limited.
- It can slide on from back or side of desk.
- It can also disassemble to attach when no space behind desk is available.
- \* Requires 0.8" (2cm) open space from edge of desk.
- · Also available as accessory.



### 3 Clamp options: 98-477: 12-18 mm (0.47"- 0.71") 98-478: 18-25 mm (0.71"- 0.98") 98-479: 25-35 mm (0.98"- 1.38")\*



\*Clamp included for North American purchases.

#### **Grommet Mount**

#### Included in some products



- Use when mounting to edge of desk is not available or not preferred.
- · Use when base does not reach edge of desk when monitors are in desired location.

  • Also available as accessory.

